

Stage 2 Kit Contents

	Per Car	PART CODE	PART DESCRIPTION
	6	ALSPCR-3412532	Aluminum Spacer 3/4 x 1/2 x 5/32
	1	ALSPCR-581414	Aluminum Spacer 5/8 x 1/4 x 1/4
	1	ASFM-6-2	Rod End M6 x 1
	5	BHCS-142012	button head cap screw, 1/4-20 x 0.5
	4	BHCS-142034	button head cap screw, 1/4-20 x 0.75
	3	BHCS-142058	button head cap screw, 1/4-20 x 0.625
	3	BJNS-6	Ball Joint, No Stud, M6 x 1 threads
	3	BJWS-6	Ball Joint, With Stud, M6 x 1 threads
	2	BJWS-6-L	Ball Joint, With Stud, M6 x 1 left threads
	1	BRKCLPR-FL	Brake Caliper, front left
	1	BRKCLPR-FR	Brake Caliper, front right
	1	BRKCLPR-RL	Brake Caliper, rear left
	1	BRKCLPR-RR	Brake Caliper, rear right
	4	BRKCLPRSPCR	Brake Caliper Spacer
	2	BRKHOS-FCOB	Front Brake Hose (Cobalt)
	2	BRKLN-CA	Brake line, control arm
	1	BRKMCADPTR-LATE	Master Cylinder Adapter, Late
	1	BRKRESADPTR-LATE	Brake Reservoir Adapter, Late
	2	BRKRTR-F	Front Brake Rotor
	2	BRKRTR-R	Rear Brake Rotor
	4	CB-38161	Carriage Bolt 3/8-16 x 1
	4	CLAMP-COATED-1	Coated Clamp 1 inch
	4	CLAMP-COATED-34	Coated Clamp 3/4 inch
	1	CLAMP-HOSE-20	Hose Clamp #20
	1	EXHSYS-TC	Exhaust system TC
	2	FTSHCK-S403	Front Shock, Single Adjustable
	2	FTSUSP-UPRT	Front Suspension Upright
	2	HHCS-1220214	hex head cap screw, 1/2-20 x 2.25
	8	HHCS-1220334	hex head cap screw, 1/2-20 x 3.75

Stage 2 Kit Contents

	Per Car	PART CODE	PART DESCRIPTION
	2	HHCS-12204	hex head cap screw, 1/2-20 x 4
	1	HHCS-14203	hex head cap screw, 1/4-20 x 3
	6	HHCS-3816112	hex head cap screw, 3/8-16 x 1.5
	8	HHCS-38162	hex head cap screw, 3/8-16 x 2
	2	HHCS-3816214	hex head cap screw, 3/8-16 x 2.25
	2	HHCS-3816234	hex head cap screw, 3/8-16 x 2.75
	2	HHCS-381634	hex head cap screw, 3/8-16 x 0.75
	2	HHCS-51618112	hex head cap screw, 5/16-18 x 1.5
	4	HHCS-51618212	hex head cap screw, 5/16-18 x 2.5
	4	HHCS-58183	hex head cap screw, 5/8-18 x 3
	2	HHCS-M12175-110	hex head cap screw, M12 x 1.75 x 110
	4	HHCS-M12175-55	hex head cap screw, M12 x 1.75 x 55
	4	NUT-3816	Nut 3/8-16
	8	NUT-JAM-1220	Jam Nut 1/2-20
	4	NUT-JAM-3416	Jam Nut 3/4-16
	6	NUT-JAM-M61	Jam Nut M6 x 1
	2	NUT-JAM-M61L	Jam Nut M6 x 1 Left
	1	NUT-NYLOK-1032	Nylok Nut 10-32
	12	NUT-NYLOK-1220	Nylok Nut 1/2-20
	5	NUT-NYLOK-1420	Nylok Nut 1/4-20
	18	NUT-NYLOK-3816	Nylok Nut 3/8-16
	4	NUT-NYLOK-5818	Nylok Nut 5/8-18
	4	RDENDMNT	Rod End Mount
	8	RIVET-18-S	Rivet 1/8 Steel Head
	8	RODEND-121220	Rod End 1/2 ball x 1/2-20
	4	RODEND-583416	Rod End 5/8 ball x 3/4-16
	1	SHCS-10322	socket head cap screw, 10-32 x 2
	1	SHFT-PSHRD-150	Pushrod 150 mm
	1	SHFT-PSHRD-200	Pushrod 200 mm

Stage 2 Kit Contents

	Per Car	PART CODE	PART DESCRIPTION
	2	SHFTBLCRNK-MAN	Shifter Bellcrank
	2	SHFTCBL-MAN	Shifter Cable Manual Trans
	1	SHFTCBL-MNT-SSR	Shifter Cable Mount SS Rear
	4	SHFTMNTSPCR-MAN	Shifter Spacer Manual
	2	SPR-2129300	Spring 2.5 inch x 9 inch x 300 lbs/in
	1	STRARM-L	Steering Arm Left
	1	STRARM-R	Steering Arm Right
	1	STRSHFTBRNGHOUS	Steering Shaft Bearing Housing
	1	STRSHFTMNT	Steering Shaft Mount
	1	STRSHFTMNTTUBE	Steering Shaft Mount Tube
	1	STRSPLNADPTR	Steering Spline Adapter
	2	STRTMNT-112NEG	Rear Strut Mount 1 1/2 Degree
	2	STRTSPCR	Strut Mount Spacer
	1	STRWHL-LAKRT	Steering Wheel
	8	SW58	Safety Washer 5/8 inch
	2	TOELINK-BOOT	Toe Link Boot
	1	TOELINK-RACK	Toe link rack
	2	TOELINK-ROD	Toe Link Tie Rod
	2	TRNSIG-MNT	Turn Signal Mount
	2	TRODEND-GF	Tie rod end Goblin front
	8	WASH-FLAT-12	Flat Washer 1/2
	12	WASH-FLAT-14	Flat Washer 1/4
	40	WASH-FLAT-38	Flat Washer 3/8 SAE
	4	WASH-FLAT-516	Flat Washer 5/16
	2	WASH-FLAT-M12	Flat Washer M12
	4	WASH-SPLIT-38	Split Washer 3/8
	4	WASH-SPLIT-516	Split Washer 5/16
	4	WASH-SPLIT-M14	Split Washer M14